

CLARKE®



CLARKE MAINTENANCE KITS



Clarke Annual Maintenance Kits have been developed with service simplicity in mind and are based on the recommendations of NFPA 25 (Standard for the Inspection, Testing, and Maintenance of water-based fire protection systems).

Designed around a two year replacement schedule, Clarke's Annual Maintenance Kits include an oil filter, fuel filter, air filter, and zinc electrode (anode). Clarke's 2nd Year Supplemental Kit includes replacement parts for common wear and tear components and coolant related items.

CLARKE®


100 Progress Place, Cincinnati, OH 45246
United States of America
Tel +1-513-475-3473 Fax +1-513-771-8930

Grange Works, Lomand Rd, Coatbridge, ML5-2NN
United Kingdom
Tel +44-1236-429946 Fax +44-1236-427274

www.clarkefire.com

CLARKE HEAT EXCHANGER COOLED ENGINE MODELS	IN STOCK	BUILT TO ORDER
	ANNUAL BOM KIT #	2 nd YEAR BOM KIT #
JU4H-UF10, 12, 20, 22, H0, H2, 40, 42, 50, 52, 58	0C12B512	Refer to Factory*
JU4H-UF14, 24	0C12C934	
JU4H-UF34, 54	0C12B514	
JU6H-UFD0, D2, 30, 32, M8, M0, M2, 58, 50, 52, 60, 62	0C12B516	
JU6H-AAPG, AAQ8, AAS0, AARG	0C12C975	
JU6H-UF34, 54, 84, 94, AAT0, AAT2, AAT8	0C12B518	
JU4H-UFADP0, R0, W8, Y8, 98, 5G	0C12B520	
JU4H-UFAEA0, AE, E8, F2, ADJ2, J8	0C12C933	
JU6H-UFADM0, NG, N0, P8, 88	0C12B522	
JU6H-UFADP0, Q0, R0, T0, R8, S8, W8, X8, 98	0C12B524	
JW6H-UFADF0, J0, 70, 80, AA60	0C12B937	
KA4H-UFKA34	0C12B943	
DP6H-UFAAX8, 88, 62, 70	0C12C105	
DQ6H-UFAA50, 60, 88, 98	0C12C082	
DR8H-UFAA40, 5G, 68, 62	0C12C080	
DS0H-UFAAM0, N0, 68, 60, 98, 92	0C12C084	
DT2H-UFAA60, 98, 92	0C12C086	
DT2H-UFAA, 58, 50, 88	0C12C088	
C18H0-UFAD18, UFAD10, UFAD32, UFAD28, UFAD20, UFAD38, UFAD42, UFAD30, UFAD48, UFAD40, UFAD58, UFAD50, UFAD68, UFAA78, UFAD78, UFAD70, UFAC18, UFAC10, UFAC28, UFAC20	0C12C935	
C18H0-UFAD12, UFAD22, UFAD32	0C12D245	
C32H0-UFAC18, UFAC12, UFAC10, UFAC28, UFAC22, UFAC20, UFAC38, UFAC32, UFAC30, UFAC48, UFAC42, UFAC40, UFAC58, UFAC52, UFAC50, UFAC68, UFAC62, UFAC60	0C12E037	

*Purchase date may determine the 2nd Year Supplemental Kit number and bill of material. Please consult factory with individual engine serial number to order.



Visit Clarkefire.com to learn more about Clarke's Annual and Supplemental Maintenance Kits.

To order, contact Clarke Customer Support by
(email) parts@clarkefire.com or (phone) +1-888-401-3473, option 1.